



**Assembly Instructions:**

1. Attach hex couplers to one rail using short SHCS.
2. Place rail with hex couplers on the right side of the forend cover.
3. Attach other rail from left side of forend cover with longer SHCS.

**Note:**  
Blue thread-locking compound can be used if desired.

DRAWN	1/27/2015	TITLE	
K. Peck		xx95TS Forend Assy - Sides	
CHECKED		SIZE	DWG NO
QA		B	forend_assy
MFG		SCALE	REV
APPROVED			01
		SHEET 1 OF 2	